

USE OF ECOSAN PRODUCTS



USE FIRST CHAMBER UNTIL IT IS FULL



WHEN THE FIRST CHAMBER IS FULL, COVER IT AND BEGIN USING THE SECOND CHAMBER UNTIL IT IS FULL



WHEN CHAMBER TWO IS FULL, REMOVE PRODUCTS FROM CHAMBER ONE AND START USING IT



LEAVE URINE IN A TIGHT CLOSED CONTAINER FOR 2 WEEKS

MIX URINE WITH WATER
IN THE RATIO OF 1:5
BEFORE APPLYING ON THE PLANTS



BURRY PRODUCTS UNDER GROUND FOR MINIMUM OF 2 WEEKS

