



**1.** Add a good quantity of leaves or hay to the pit to stimulate the start of the composting.



**2.** Place the slab on the pit.



**3.** Cover the second pit – you can use it for composting while waiting for the first one to fill up.



**4.** Connect the urine pipe to the jerry can.



**5.** Prepare and place a pot with soil/ash mixture within reach for the user.

**Now the toilet is ready to use!**