



1. Add ash or straw on the bottom of the vault to absorb humidity and avoid that the faeces sticks to the bottom.



2. Close off the vaults with bricks and light mortar to avoid that water and flies can enter.



3. Connect the urine pipe to the jerry can.



4. Make sure that the anal cleansing water enters the small soak away.



5. Prepare and place a pot with ash within reach of the user.

Now the toilet is ready to use!