

The urinals and latrines in the PS-Aguié project allow to collect urine in jerry cans. When a jerry can is replaced by an empty one. The full jerry can is stored for one month, protected from the sun.



Simple urinal.



Urine from a dry toilet.



Urine from a composting toilet.

## Changing the jerry can of a dry toilet and composting toilet:



1. The jerry can is full.



2. Unscrew the lid.



3. Leave the lid on the pipe and take out the jerry can.



4. Take the lid off the new jerry can and close the full one.



5. Replace the pipe with the lid on the new jerry can.



6. Store the full jerry can for at least 30 days to eliminate pathogens. Avoid sunlight to protect the plastic from degrading.

### Important information:

- If there is no empty jerry cans available:
  - Add the urine to the compost or dirt pile (dig first, and cover afterwards to avoid that the nitrogen fertilizer is lost to the air)
  - Apply the urine to the field during the dry season (preparing the land for the rainyseason) ~ 0,5 litres per pocket and cover up with soil.